



# KeyMission 360™

Directions for pairing with iPhone®  
or iPad® via Bluetooth® and Wi-Fi®

MISSION 360° I AM ON MISSION 360° I AM ON MIS



At the heart of the image™




CAMERA PREP:


# Preparing the camera

## MAKE SURE...


- 1 **Battery** is fully charged *(see manual "Charging the Battery" page 6)*
- 2 **Micro SD card** with sufficient space has been installed *(see page 4)*
- 3 **Airplane Mode** has been shut off *(see page 9)*
- 4 Camera is shut **OFF** *(if not hold down video button for 3 seconds)*




Open Door



Battery latch



Memory card slot



Airplane mode OFF



Close Door

SMART DEVICE:

# Check Smart Device Settings

MAKE SURE... • **Wi-Fi** setting is ON • **Bluetooth** setting is ON

*Go to  
"Settings"  
on your  
smart  
device*



*Make sure  
Wi-Fi is ON*



*Make sure  
Bluetooth is ON*

For latest firmware and app information [www.nikonusa.com](http://www.nikonusa.com)

APP DOWNLOAD:

# Download SnapBridge 360/170 App

- Go to the **App Store** on your smart device
- Search for **SnapBridge 360/170** and select correct app
- **Download and Install** SnapBridge 360/170
- Go back to your home screen and **click on app**



Download / Install  
SnapBridge 360/170 App

## BLUETOOTH PAIRING:

# Pairing the Camera

### ON YOUR SMART DEVICE

Launch **SnapBridge 360/170** on your smart device



### ON YOUR CAMERA

**Press and Hold** movie button until the green status lamps flash **simultaneously**...




...then flash **alternately**.

*When that happens, camera is in pairing standby mode.*

### ON YOUR SMART DEVICE


Tap the camera name when it appears.




*Note: Only pair the camera using the Snapbridge 360/170 app (Do not try and pair from device Bluetooth setting!)*

Tap your camera once it appears in the list.

*(It may take a few seconds)*



You can either choose to continue as a guest or sign up for a Nikon ID. After you have done this, you will be taken back to the Connect tab.



You are now paired via Bluetooth®. The next thing you will see is this window, letting you know that you need to switch to a Wi-Fi connection to use remote photography or download stills and videos from the camera. **Tap OK.**



*This symbol means you are paired with Bluetooth*


If you need to un-pair and re-pair your iPhone® or iPad® and the KeyMission 360 camera, read this article for detailed instructions on how to do so. Go to [www.nikon.usa/keymission360](http://www.nikon.usa/keymission360)

## REMOTE PHOTOGRAPHY:


If you want to shoot remotely or download stills or videos, you will need to connect to the camera's Wi-Fi between the KeyMission 360 camera and the SnapBridge 360/170 app.

Make sure to turn on Wi-Fi in the Wi-Fi settings of your smart device


Select the **Camera** icon on the app.



Tap **Remote photography**.




Wi-Fi has been enabled on the camera. Tap **Go** on your device to be taken to your device's Wi-Fi settings.




## CONNECTING TO Wi-Fi:

# Connecting to Wi-Fi


Tap settings to go to your device's Wi-Fi settings



Select Wi-Fi



Tap Your KeyMission camera when it appears



*Note: The app will ask for permission to turn on Wi-Fi when needed. This conserves camera battery power.*

## REMOTE SHOOTING:

# Start remote shooting

Enter the default password and tap join:\*

## NikonKeyMission

*\*Note that it is case sensitive and you only have to do this once)*

Enter the password for "KM360\_30000031"

[Cancel](#) **Enter Password** [Join](#)


Password **NikonKeyMission**

We recommend that you change the password to a personal one. To do so, within the app., go to:  
Camera Settings >  
Network Menu >  
Wi-Fi >  
Network Settings

Go back to to SnapBridge 360/170 app and choose **Remote photography** again.



KeyMission 360 are now connected via both Bluetooth® and Wi-Fi. You can now shoot remotely from your smart device (you can also change settings on the camera via the SnapBridge 360/170 app).



*You will see a "live view" of what your camera sees. This is a low resolution view and not indicative of the video quality*

DOWNLOADING:

# Downloading Videos / Stills



- 1** Navigate to the Camera Tab and Select **'Download Selected Pictures'**



- 2** When prompted to go to Wi-Fi settings, press **'Go'**

- 3** Navigate back to the main settings menu and go to **Wi-Fi settings**




- 4** Make sure your smart device connects to the camera's wireless network. This should happen automatically after the initial Wi-Fi set-up



5 Return to SnapBridge 360/170 app and choose **'Download Selected Pictures'** again

6 Select the video you want to download and press **'Download'** to download it to your device


7 You may see the following prompt: ***'To reduce the time required, download will begin when there is more bandwidth available. OK?'*** If you see this, just press **'OK'** and your download will begin




SHARING:

# Saving videos for YouTube™ & Facebook®


- 1 Select the edit icon and choose **'Add YouTube metadata'**
- 2 If prompted to save the file separately or erase the original, select **'Yes'** or 'No'
- 3 When the edit screen returns, press **'Cancel'**



- 4 Return to the gallery and **select the new file** with metadata added



- 5 Press the **'Share'** button and choose Facebook® or YouTube™



- 6 Follow instructions in Facebook® or YouTube™ to upload and show your movies or photos.

# For Assistance With Your Camera Set Up We've Included Various FREE Resources For You To Explore:

NEED ASSISTANCE?



**Nikon** CUSTOMER SUPPORT

Dial **1-800-645-6687**  
or online at:  
**nikonusa.com/support**



WEB RESOURCES

LEARN MORE ABOUT THE KEYMISSION 360

Nikon Learn & Explore:

**nikonusa.com/KM360**

FOR MORE INFORMATION GO TO

**nikonusa.com**

FOLLOW US ON

TWITTER: **#nikonusa**

FACEBOOK: **facebook.com/nikon**

#### ± WI-FI COMPATIBILITY

This camera's built-in Wi-Fi<sup>®</sup> capability can only be used with a compatible iPhone<sup>®</sup>, iPad<sup>®</sup>, and/or iPod touch<sup>®</sup> or smart devices running on the Android<sup>™</sup> operating system. The Nikon SnapBridge 360/170 application must be installed on the device before it can be used with this camera.

#### System Requirements

Android 5.0 or later or 6.0.1 or later. Android 7 or later is not supported (an update will be issued when compatibility has been confirmed. There is no guarantee that this app will run on all Android devices). iOS 8.4 or later, iOS 9.1 or later (latest version of iOS 8 or iOS 9 recommended) plus iOS 10.2 for KeyMission 360. The KeyMission 360 firmware must be updated to ensure compatibility with iOS 10.2. A device with Bluetooth 4.0 or later (i.e., a device that supports Bluetooth Smart Ready/Low Energy) is required. There is no guarantee that this app will run on all devices.



Apple, the Apple logo, iPhone, iPad and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Wi-Fi<sup>®</sup> and the Wi-Fi CERTIFIED logo are registered trademarks of the Wi-Fi Alliance.

The Bluetooth<sup>®</sup> word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Nikon Corporation and its Affiliates is under license.

All Nikon trademarks are trademarks of Nikon Corporation.

You Tube is a trademark of Google Inc. Facebook is a trademark of Facebook Inc.