



LIMITATIONS REGARDING WATERPROOF, DUSTPROOF, FREEZEPROOF AND SHOCKPROOF ATTRIBUTES OF THE NIKON KeyMission 360

The waterproof, dustproof, freezeproof and shockproof performances described below do not ensure the Camera will remain completely waterproof or that the Camera will be free from damage or trouble under all conditions.

Wireless communications are not available under water.

Waterproof and Dustproof Attributes

- Camera is rated equivalent to JIS/IEC waterproof grade 8 (IPX8) and JIS/IEC dustproof grade 6 (IP6X) and can shoot images underwater at a depth of 30 meters (98 feet) for up to 60 minutes. Please note: full 360 images cannot be captured underwater when using underwater lens protectors. Images captured underwater may be blurred.
- Do not use the camera deeper than 20 meters (65 feet) when the AA-14A lens protectors are attached.
- Camera for use in fresh water (swimming pools, rivers and lakes) and seawater only and not with any other type of liquid. Waterproof performance not rated for other liquids. The waterproof performance of this camera was tested in fresh water (Swimming pools, rivers, and lakes) and salt water only.
- Do not drop the camera, strike it against a hard object such as a rock, or throw it against a water surface.
- Do not subject the camera to shock when using it underwater.
- Do not subject the camera to water pressure by exposing it to rapids or waterfalls.
- Do not use the camera deeper than 30 meters (98 feet) underwater.
- Make sure not to drop the camera underwater. This camera does not float in water.
- Do not continuously use the camera underwater for 60 minutes or more.
- Do not allow water to seep inside the Camera. The inner portion of this Camera is not waterproof. Water seeping inside the Camera could cause components to rust, resulting in high repair costs or irreparable damage.
- Do not insert a wet memory card or battery in the Camera.
- Camera's battery-chamber/memory card slot cover should not be opened or closed under wet conditions, near a waterfront and/or underwater. This could cause water to seep inside the Camera or result in Camera malfunction.
- Do not handle, open or close the Camera cover with wet hands. This could cause water to seep inside the Camera or result in Camera malfunction.
- If moisture such as water droplets adheres to the outside of the camera or inside the battery-chamber/memory card slot cover, immediately wipe it off with a soft dry cloth.
- If a foreign substance adheres to the outside of the camera or the inside of the

battery-chamber/memory card slot cover, immediately remove it with a blower or a soft cloth.

- Do not open the battery-chamber/memory card slot cover until all foreign substances are wiped off.
- Camera should not be left in low temperature conditions in cold climate regions or in high-temperature conditions of 40°C (104°F) or more for a long period of time. This could cause deterioration of the waterproof performance.
- Do not subject the Camera to excessive shock, vibration or pressure by dropping it, hitting it, or placing a heavy object on it, as this could cause water to seep inside the Camera and result in Camera malfunction.
- Camera can be used under water only in water temperatures ranging from 0°C to 40°C (32°F to 104°F).
- If the Camera is exposed to shock, it is recommended that you consult your retailer or Nikon-authorized service representative to confirm the waterproof performance.
- The waterproof performance of waterproof packing may start to deteriorate after one year. If the waterproof packing begins to deteriorate, consult your retailer or Nikon-authorized service representative. There is a charge for this service.
- Do not open the Camera battery-chamber/memory card slot cover underwater.
- Camera must be cleaned within sixty minutes after using the Camera underwater.
- Do not use soap, neutral detergents, or chemicals such as benzene for cleaning.
- Do not puncture the microphone or speaker openings with a sharp implement. If the inside of the camera is damaged, the waterproof performance will deteriorate.

Freezeproof Attributes

- The operation of this Camera has been tested at temperatures from -10°C to +40°C (14°F to 104°F).
- Battery performance deteriorates temporarily when cold. Keep the camera and batteries warm under your clothing before use.
- Fogging (condensation) may occur on the inside of the lenses, lens protectors, or underwater lens protectors when there are sharp temperature changes or high humidity, such as in the environmental conditions described below. This is not a camera malfunction or defect.
 - The camera is suddenly immersed in cold water after being in a hot place on land.
 - The camera is brought to a warm place such as inside a building after being in the cold outdoors.
 - The battery-chamber/memory card slot cover is opened or closed in a high-humidity environment.
 - The camera, lens protectors, or underwater lens protector are still wet when they are attached to each other.
 - The camera is used for an extended period of time in a low-temperature environment.

Shockproof Attributes

- Camera has passed Nikon's in-house test (drop test from a height of 200 cm (6 ft. 6 in.) on a 5 cm (2 in.) thick plywood panel) compliant with MIL-STD 810F Method 516.5-Shock. However, shock may cause changes in appearance, such as paint peeling off and deformation of the camera.
- Do not subject the Camera to excessive shock, vibration or pressure by dropping it, hitting it, or placing a heavy object on it, as this could deform the camera.



LIMITATIONS REGARDING WATERPROOF, DUSTPROOF, FREEZEPROOF AND SHOCKPROOF ATTRIBUTES OF THE NIKON KeyMission 170

The waterproof, dustproof, freezeproof and shockproof performances described below do not ensure the Camera will remain completely waterproof or that the Camera will be free from damage or trouble under all conditions.

Wireless communications are not available under water.

Waterproof and Dustproof Attributes

- Camera is rated equivalent to JIS/IEC waterproof grade 8 (IPX8) and JIS/IEC dustproof grade 6 (IP6X) and can shoot images underwater at a depth of 10 meters (33 feet) for up to 60 minutes.
- Camera for use in fresh water (swimming pools, rivers and lakes) and seawater only and not with any other type of liquid. Waterproof performance not rated for other liquids. The waterproof performance of this camera was tested in fresh water (swimming pools, rivers, and lakes) and salt water only.
- Do not drop the camera, strike it against a hard object such as a rock, or throw it against a water surface.
- Do not subject the camera to shock when using it underwater.
- Do not subject the camera to water pressure by exposing it to rapids or waterfalls.
- Do not use the camera deeper than 10 meters (33 feet) underwater.
- Make sure not to drop the camera underwater. This camera does not float in water.
- Do not continuously use the camera underwater for 60 minutes or more.
- Do not allow water to seep inside the Camera. The inner portion of this Camera is not waterproof. Water seeping inside the Camera could cause components to rust, resulting in high repair costs or irreparable damages.
- Do not insert a wet memory card or battery in the Camera.
- Camera's battery-chamber/memory card slot cover should not be opened or closed under wet conditions, near a waterfront and/or underwater. This could cause water to seep inside the Camera or result in Camera malfunction.
- Do not handle, open or close the Camera cover with wet hands. This could cause water to seep inside the Camera or result in Camera malfunction.
- If moisture such as water droplets adheres to the outside of the camera or inside the battery-chamber/memory card slot cover, immediately wipe it off with a soft dry cloth.
If a foreign substance adheres to the outside of the camera or the inside of the battery-chamber/memory card slot cover, immediately remove it with a blower

or a soft cloth.

- Do not open the battery-chamber/memory card slot cover until all foreign substances are wiped off.
- Camera should not be left in low temperature conditions in cold climate regions or in high-temperature conditions of 40°C (104°F) or more for a long period of time. This could cause deterioration of the waterproof performance.
- Do not subject the Camera to excessive shock, vibration or pressure by dropping it, hitting it, or placing a heavy object on it, as this could cause water to seep inside the Camera and result in Camera malfunction.
- Camera can be used under water only in water temperatures ranging from 0°C to 40°C (32°F to 104°F).
- If the Camera is exposed to shock, it is recommended that you consult your retailer or Nikon-authorized service representative to confirm the waterproof performance.
- The waterproof performance of waterproof packing may start to deteriorate after one year. If the waterproof packing begins to deteriorate, consult your retailer or Nikon-authorized service representative. There is a charge for this service.
- Do not open the Camera battery-chamber/memory card slot cover underwater.
- Do not use soap, neutral detergents, or chemicals such as benzene for cleaning.
- Do not puncture the microphone or speaker openings with a sharp implement. If the inside of the camera is damaged, the waterproof performance will deteriorate.

Freezeproof Attributes

- The operation of this Camera has been tested at temperatures from -10°C to +40°C (14°F to 104°F).
- Battery performance deteriorates temporarily when cold. Keep the camera and batteries warm under your clothing before use.
- Camera performance may deteriorate temporarily if it is exposed to extreme cold for an extended period. For example, the monitor may appear darker than normal immediately after the camera is turned on, or residual images may be produced.
- Fogging (condensation) may occur on the inside of the lenses when there are sharp temperature changes or high humidity, such as in the environmental conditions described below. This is not a camera malfunction or defect.
 - The camera is suddenly immersed in cold water after being in a hot place on land.
 - The camera is brought to a warm place such as inside a building after being in the cold outdoors.
 - The battery-chamber/memory card slot cover is opened or closed in a high-humidity environment.

Shockproof Attributes

- Camera has passed Nikon's in-house test (drop test from a height of 200 cm (6 ft. 6 in.) on a 5 cm (2 in.) thick plywood panel) compliant with MIL-STD 810F Method

516.5-Shock. However, shock may cause changes in appearance, such as paint peeling off and deformation of the drop shock portion.

- Do not subject the Camera to excessive shock, vibration or pressure by dropping it, hitting it, or placing a heavy object on it, as this could deform the Camera.

Remote Control (Supplied Accessory)

- The remote control is rated equivalent to JIS/IEC waterproof grade 7 (IPX7), and it is confirmed that water does not seep inside when soaked underwater at a depth of 1 meter (3.2 feet) for up to 30 minutes.
 - The remote control cannot be used underwater.
- Do not drop the remote control, strike it against a hard object such as a rock, or throw it against a water surface.
- Do not take the remote control underwater.
 - If the remote control is dropped in water by accident, immediately pick it up and wipe it off with a soft dry cloth.
- Do not insert a wet battery in the remote control.
- Do not open the battery-chamber cover when the remote control or your hands are wet. Doing so may cause water to seep inside the remote control or result in camera malfunction.
- If moisture such as water droplets or a foreign substance adheres to the outside of the remote control or the inside of the battery-chamber cover, immediately wipe it off with a soft dry cloth.
- Do not leave the remote control in cold conditions or in hot conditions of 40°C (104°F) or more for a long period of time.
 - Doing so could cause deterioration of the waterproof performance.
- Do not suddenly bring the remote control to high-humidity environment if it is exposed to extreme cold for an extended period.
 - Condensation may form inside the remote control.



LIMITATIONS REGARDING WATERPROOF, DUSTPROOF, FREEZEPROOF AND SHOCKPROOF ATTRIBUTES OF THE NIKON KeyMission 80

The waterproof, dustproof, freezeproof and shockproof performances described below do not ensure the Camera will remain completely waterproof or that the Camera will be free from damage or trouble under all conditions.

Wireless communications are not available under water.

The camera cannot be used underwater.

Waterproof and Dustproof Attributes

- Camera is rated equivalent to JIS/IEC waterproof grade 7 (IPX7) and JIS/IEC dustproof grade 6 (IP6X). Waterproofing prevents water from entering the camera underwater up to 30 minutes at a depth of 1 M (3.3 ft.).
- The waterproof performance of this camera was tested in fresh water (swimming pools, rivers, and lakes) and salt water only. Camera for use in fresh water (swimming pools, rivers and lakes) and seawater only and not with any other type of liquid. Waterproof performance not rated for other liquids.
- Do not drop the camera, strike it against a hard object such as a rock, or throw it against a water surface.
- Do not subject the camera to shock underwater.
- Do not subject the camera to water pressure by exposing it to rapids or waterfalls.
- Make sure not to drop the camera underwater. This camera does not float in water.
- Do not continuously immerse the camera in water for 30 minutes or more.
-
- Do not allow water to seep inside the Camera. The inner portion of this Camera is not waterproof. Water seeping inside the Camera could cause a malfunction.
- Do not insert a wet memory card or battery in the Camera.
- Camera's memory card slot/connector cover should not be opened or closed under wet conditions, near a waterfront and/or underwater. This could cause water to seep inside the Camera or result in Camera malfunction.
- Do not handle, open or close the Camera cover with wet hands. This could cause water to seep inside the Camera or result in Camera malfunction.
- If moisture such as water droplets adheres to the outside of the camera or inside the memory card slot/connector cover, immediately wipe it off with a soft dry cloth.
- If a foreign substance adheres to the outside of the camera or the inside of the

memory card slot/connector cover, immediately remove it with a blower or a soft cloth.

- Do not open the memory card slot/connector cover until all foreign substances are wiped off.
- Camera should not be left in low temperature conditions in cold climate regions or in high-temperature conditions of 40°C (104°F) or more for a long period of time. This could cause deterioration of the waterproof performance.
- Camera can be used under water only in water temperatures ranging from 0°C to 40°C (32°F to 104°F).
- The waterproof performance of waterproof packing may start to deteriorate after one year. If the waterproof packing begins to deteriorate, consult your retailer or Nikon-authorized service representative. There is a charge for this service.
- Do not open the Camera memory card slot/connector cover underwater.
- Do not use soap, neutral detergents, or chemicals such as benzene for cleaning.
- Do not puncture the microphone or speaker openings with a sharp implement. If the inside of the camera is damaged, the waterproof performance will deteriorate.

Freezeproof Attributes

- The operation of this Camera has been tested at temperatures from -10°C to +40°C (14°F to 104°F).
- Battery performance deteriorates temporarily when cold. Keep the camera and batteries warm under your clothing before use.
- Camera performance may deteriorate temporarily if it is exposed to extreme cold for an extended period.
- Fogging (condensation) may occur on the inside of the lenses when there are sharp temperature changes or high humidity, such as in the environmental conditions described below. This is not a camera malfunction or defect.
 - The camera is suddenly immersed in cold water after being in a hot place on land.
 - The camera is brought to a warm place such as inside a building after being in the cold outdoors.
 - The memory card slot/connector cover is opened or closed in a high-humidity environment.

Shockproof Attributes

- Camera has passed Nikon's in-house test (drop test from a height of 150 cm (4 ft. 11 in.) on a 5 cm (2 in.) thick plywood panel) compliant with MIL-STD 810F Method 516.5-Shock. However, shock may cause changes in appearance, such as paint peeling off and deformation of the Camera.
- Do not subject the Camera to excessive shock, vibration or pressure by dropping it, hitting it, or placing a heavy object on it, as this could deform the Camera.

